

Design and Construction Guides

- Engineered Wood Construction Guide, *Form E30*
- Build a Better Home: Foundations, *Form A520*
- Build a Better Home: Mold and Mildew, *Form A525*
- Build a Better Home: Walls, *Form A530*
- Build a Better Home: Roofs, *Form A535*
- Narrow Walls That Work, *Form D420*
- Technical Note: Using Wood Structural Panels for Combined Uplift and Shear Resistance, *Form E510*
- Intro to Wall Bracing, *Form F430*
- Wind-Rated Roofs, *Form G310*
- Whole House Bracing, *Form G440*
- Designing for Combined Shear and Wind Uplift, *Form K325*
- Technical Note: Sprinkler Installation for APA Performance Rated I-Joists, *Form J745*
- Data File: Installation and Preparation of Plywood Underlayment for Resilient Floor Covering, *Form L335*
- APA System Report: Design for Combined Shear and Uplift from Wind, *Form SR-101*
- Wood Structural Panels Over Metal Framing, *Form T625*
- Concrete Forming, *Form V345*
- Technical Note: Jumbo Panels for Nonresidential Roofs, *Form W220*
- Fire-Rated Systems, *Form W305*
- Noise-Rated Systems, *Form W460*
- Introduction to Lateral Design, *Form X305*

Engineered Wood Product Guides

- Data File: 303 Siding Manufacturing Specifications, *Form B840*
- Glulam Floor Beams, *Form C415*
- A Guide to Engineered Wood Products, *Form C800*
- Product Guide: Performance Rated Siding, *Form E300*
- Performance Rated Panels, *Form F405*
- Panelized Roofs, *Form G630*
- Sanded Plywood, *Form K435*
- EWS Technical Note: Glulam Connection Details, *Form T300*
- Voluntary Product Standard, PS 1-09, Structural Plywood, *Form L870*
- APA Performance Rated Rim Boards, *Form W345*
- Oriented Strand Board, *Form W410*
- EWS Product Guide: Glulam, *Form X440*
- APA Performance Rated I-Joists, *Form Z725*

Case Studies

- Palmer Events Center, *Form C120*
- APA Re-Siding Project, *Form F110*
- Caldera Hearth Center, *Form F115*
- Las Vegas Elementary School, *Form F120*
- Wood Sheathing Builds Business, *Form F125*
- The Village at Germantown, *Form G110*
- Glulam in Golf Resort Construction, *Form G225*
- Raised Wood Floors: Case Studies in Progressive Home Construction, *Form K110*
- Environmental Nature Center, *Form K115*
- Wisconsin Visitors Information Center, *Form W110*
- Washington State History Museum, *Form W115*
- Anaheim Ice Rink, *Form W120*
- Investco, *Form W125*
- Park 277, *Form W140*
- Fred Meyer, *Form W145*
- REI Flagship Store, *Form W155*
- Pepsi Distribution Center, *Form W160*
- Redlin Art Museum, *Form X110*
- Holland Pork Company, *Form X120*
- Portland Bulk Storage, *Form X140*
- Bear Hill Condominiums, *Form X160*
- Microtel Inn, *Form X165*

Builder Tips

- APA Narrow Wall Bracing Method Framing Tips, *Form F435*
- How To Minimize Buckling of Asphalt Composition Shingles, *Form K310*
- Cut Callbacks with Proper Spacing and Nailing, *Form M300*
- APA Panels For Soffit Applications, *Form N330*
- Proper Installation of APA Rated Sheathing for Roof Applications, *Form N335*
- Steps to Construct a Solid, Squeak-Free Floor System, *Form Q300*
- Finishing APA Rated Siding, *Form Q350*
- Proper Selection and Installation of APA Plywood Underlayment, *Form R340*
- Worker Safety on Pitched Roofs, *Form S200*
- Minimize Nail Pops, *Form S300*
- Storage and Handling of APA Trademarked Panels, *Form U450*
- Rim Board Installation & Connection Details, *Form Z730*
- Storage, Handling & Safety Recommendations for APA Performance Rated I-Joists, *Form Z735*

General Information

- APA Member and Product Directory, *Form K815*
- APA Publication Index, *Form B300*
- EWS Publication Index, *Form S400*
- Wood: Sustainable Building Solutions, *Form F305*