

Design & Construction Guides

- Engineered Wood Construction Guide, Form E30
- Build a Better Home: Foundations, Form A520
- Build a Better Home: Mold and Mildew, Form A525
- Build a Better Home: Walls, Form A530
- Build a Better Home: Roofs, Form A535
- Introduction to Wall Bracing, Form F430
- Glulam in Golf Resort Construction, Form G225
- Wind-Rated Roofs: Designing Commercial Roofs to Withstand Wind Uplift Forces, Form G310
- Brace Walls with Wood, Form G440
- Build Profit with Wood Walls, Form J435
- Build Energy Efficient Walls, Form J440
- Technical Note: Sprinkler Installation for APA Performance Rated I-Joists, *Form J745*
- Designing for Combined Shear and Wind Uplift, *Form K325*
- Data File: Installation and Preparation of Plywood Underlayment for Resilient Floor Covering, Form L335
- Data File: Installation of Stucco Exterior Finish Over Wood Structural Panel Wall Sheathing, Form Q370
- APA System Report: Design for Combined Shear and Uplift from Wind, *Form SR-101*
- Data File: Roof Sheathing Fastening Schedules for Wind Uplift, Form T325
- Concrete Forming, Form V345
- Fire-Rated Systems, Form W305
- Noise-Rated Systems, Form W460

Engineered Wood Product Guides

- A Guide to Engineered Wood Products, *Form C800*
- Product Guide: Performance Rated Siding, *Form E300*
- Performance Rated Panels, *Form F405*
- Sanded Plywood, *Form K435*
- APA Performance Rated Rim Boards, *Form W345*
- Oriented Strand Board, *Form W410*
- EWS Product Guide: Glulam, *Form X440*
- APA Performance Rated I-Joists, *Form Z725*

Case Studies

- Palmer Events Center, *Form C120*
- Wood Sheathing Builds Business, *Form F125*
- The Village at Germantown, *Form G110*
- Atlantic Station Condominiums, *Form J130*
- Great Wolf Lodge, *Form J135*
- Cathedral of Christ the Light, *Form J140*
- Raised Wood Floors: Case Studies in Progressive Home Construction, *Form K110*

- Environmental Nature Center, *Form K115*
- Wisconsin Visitors Information Center, *Form W110*
- Washington State History Museum, *Form W115*
- Anaheim Ice Rink, *Form W120*
- Investco, *Form W125*
- Park 277, *Form W140*
- Fred Meyer, *Form W145*
- REI Flagship Store, *Form W155*
- Pepsi Distribution Center, *Form W160*
- Redlin Art Museum, *Form X110*
- Holland Pork Company, *Form X120*
- Portland Bulk Storage, *Form X140*
- Bear Hill Condominiums, *Form X160*
- Microtel Inn, *Form X165*

Builder Tips

- How To Minimize Buckling of Asphalt Composition Shingles, *Form K310*
- APA Narrow Wall Bracing Method Framing Tips, *Form F435*
- Spanish version: APA Narrow Wall Bracing Method Framing Tips, *Form F435LA*
- Minimize Glulam Checking Through Proper Storage and Handling, *Form F455*
- Cut Callbacks with Proper Spacing, *Form M300*
- APA Panels For Soffit Applications, *Form N330*
- Proper Installation of APA Rated Sheathing for Roof Applications, *Form N335*
- Steps to Construct a Solid, Squeak-Free Floor System, *Form Q300*
- Finishing APA Rated Siding, *Form Q350*
- Proper Handling and Installation of APA Plywood Underlayment, *Form R340*
- Worker Safety on Pitched Roofs, *Form S200*
- Minimize Nail Pops, *Form S300*
- Storage and Handling of APA Trademarked Panels, *Form U450*
- Storage, Handling & Safety Recommendations for APA Performance Rated I-Joists, *Form Z735*

General Information

- APA Member and Product Directory, *Form K815*
- APA Publication Index, *Form B300*
- APA Research Index, *Form T810*
- Wood: Sustainable Building Solutions, *Form F305*

