

Design & Construction Guides

- Engineered Wood Construction Guide, *Form E30*
- Post Frame, *Form A475*
- Build a Better Home: Foundations, *Form A520*
- Build a Better Home: Mold and Mildew, *Form A525*
- Build a Better Home: Walls, *Form A530*
- Build a Better Home: Roofs, *Form A535*
- Wind Rated Roofs, *Form G310*
- Brace Walls with Wood, *Form G440*
- Data File: Installation and Preparation of Plywood Underlayment for Resilient Floor Covering, *Form L335*
- Diaphragms and Shear Walls, *Form L350*
- Materials Handling, *Form M200*
- Earthquake Safeguards, *Form R240*
- Industrial Panel Selection Guide, *Form T200*
- Concrete Forming, *Form V345*
- Technical Note: Jumbo Panels for Nonresidential Roofs, *Form W220*
- Noise-Rated Systems, *Form W460*
- Introduction to Lateral Design, *Form X305*
- PRI-400, Performance Standard for APA EWS I-Joists, *Form X720*
- Short Form for Panels, *Form Y310*

Engineered Wood Product Guides

- MDO/HDO Plywood, *Form B360*
- Data File: 303 Siding Manufacturing Specifications, *Form B840*
- A Guide to Engineered Wood Products, *Form C800*
- Product Guide: Performance Rated Siding, *Form E300*
- Performance Rated Panels, *Form F405*
- Sanded Plywood, *Form K435*
- Voluntary Product Standard, PS 1-09, Structural Plywood, *Form L870*
- EWS Rim Board, *Form W345*
- Oriented Strand Board, *Form W410*
- EWS Product Guide: Glulam, *Form X440*
- Panel Handbook and Grade Glossary, *Form X505*
- APA Performance Rated I-Joists, *Form Z725*

Case Studies

- National Heritage Academy, *Form A110*
- Beaverton City Library, *Form A115*
- Weiden & Kennedy Corporate Headquarters, *Form A120*
- Albert Lea High School, *Form B115*
- Engineered Wood in School Design, *Form B210*
- Autzen Football Stadium, *Form C110*
- City Reservoir Covers, *Form C115*
- Palmer Events Center, *Form C120*
- The Village at Germantown, *Form G110*
- Three Village Green - The Pines, *Form G150*
- Eastlake Design District, *Form G155*
- Lake View Terrace Branch Library, *Form G160*
- Borough Branch YMCA, *Form G165*
- Atlantic Station Condominiums, *Form J130*
- Great Wolf Lodge, *Form J135*
- Cathedral of Christ the Light, *Form J140*
- Raised Wood Floors: Case Studies in Progressive Home Construction, *Form K110*
- Environmental Nature Center, *Form K115*
- Wisconsin Visitors Information Center, *Form W110*
- Washington State History Museum, *Form W115*
- Anaheim Ice Rink, *Form W120*
- Investco, *Form W125*
- Park 277, *Form W140*
- Fred Meyer, *Form W145*
- REI Flagship Store, *Form W155*
- Pepsi Distribution Center, *Form W160*
- Redlin Art Museum, *Form X110*
- Holland Pork Company, *Form X120*
- Portland Bulk Storage, *Form X140*
- Bear Hill Condominiums, *Form X160*
- Microtel Inn, *Form X165*
- Liberty High School, *Form Y115*
- Northgate Mall, *Form Y120*

Builder Tips

- I-Joist Web Stiffeners, *Form A745*
- I-Joist Blocking, *Form A750*
- I-Joist Squash Blocks, *Form A755*
- I-Joist Filler Blocks, *Form A760*
- I-Joist Backer Blocks, *Form A765*
- How To Minimize Buckling of Asphalt Composition Shingles, *Form K310*
- APA Narrow Wall Bracing Method Framing Tips, *Form F435*
- Minimize Glulam Checking Through Proper Storage and Handling, *Form F455*
- Cut Callbacks with Proper Spacing, *Form M300*
- APA Panels For Soffit Applications, *Form N330*
- Proper Installation of APA Rated Sheathing for Roof Applications, *Form N335*
- Steps to Construct a Solid, Squeak-Free Floor System, *Form Q300*
- Finishing APA Rated Siding, *Form Q350*
- Proper Handling and Installation of APA Plywood Underlayment, *Form R340*
- Worker Safety on Pitched Roofs, *Form S200*

- Minimize Nail Pops, *Form S300*
- Storage and Handling of APA Trademarked Panels, *Form U450*
- Storage, Handling & Safety Recommendations for APA Performance Rated I-Joists, *Form Z735*

Troubleshooting

- Technical Note: Floor Squeaks - Causes, Solutions and Prevention, *Form C468*
- Customer Service Tip: Unevenness Of Edges In Wood Structural Panels And Thin Underlayment, *Form C501*
- Technical Note: Buckling of Panel Sheathing, *Form D481*
- Technical Note: Buckling of Wood-Based Panel Siding, *Form F410*
- Customer Service Tip: Panel Troubleshooting, *Form F505*
- Technical Note: Field Repairs of Plywood, *Form J805*
- Technical Note: Water Vapor Permeance of Wood Structural Panels and Wood Wall Construction, *Form J450*
- Technical Note: Sprinkler Installation for APA Performance Rated I-Joists, *Form J745*
- Technical Note: Mildew Discoloration of Wood Siding, *Form L805*
- Technical Note: Staining Of Finishes From Water-Soluble Wood Extractives, *Form L810*
- Technical Note: Jumbo Panels for Nonresidential Roofs, *Form W220*
- Customer Service Tip: Soft Structural Panels, *Form W501*
- Customer Service Tip: Ridging In Single Layer Floor Panels, *Form W503*
- Customer Service Tip: Delamination Of Plywood Panels, *Form W504*
- Customer Service Tip: Decay Of Engineered Wood Products, *Form W505*
- Customer Service Tip: Checking, *Form W506*
- Technical Note: Condensation Causes and Control, *Form X485*
- Customer Service Tip: Assessing Water Damage After A Flood, *Form X501*

General Information

- APA Member and Product Directory, *Form K815*
- APA Publication Index, *Form B300*
- APA Research Index, *Form T810*
- EWS Publication Index, *Form S400*
- Wood: Sustainable Building Solutions, *Form F305*

