

# Shelton Structural Glued Laminated Timber PR-L321 Shelton Structures Inc. dba Revised March 9, 2024 Shelton Lam and Deck

Products: Shelton Glulam Columns

Shelton Structures Inc. dba Shelton Lam and Deck, 192 Downie Road, Chehalis, WA 98532 (360) 740-1008

## 1. Basis of the product report:

- 2021, 2018, 2015, and 2012 International Building Code (IBC): Sections 104.11
   Alternative materials and 2303.1.3 Structural glued laminated timber
- 2021, 2018, and 2015 International Residential Code (IRC): Sections R104.11 Alternative materials, and R502.1.3, R602.1.3, and R802.1.2 Structural glued laminated timber
- 2012 IRC: Sections R104.11 Alternative materials, and R502.1.5, R602.1.2, and R802.1.4 Structural glued laminated timber
- ANSI 117-2020 and ANSI 117-2015 recognized in the 2021 IBC and IRC, and 2018 IBC and IRC, respectively
- ANSI A190.1-2017, ANSI A190.1-2012, and ANSI/AITC A190.1-2007 recognized in the 2021 and 2018 IBC and IRC, 2015 IBC and IRC, and 2012 IBC and IRC, respectively
- ASTM D3737-18e1, D3737-12 and D3737-08 recognized in the 2021 IBC and IRC, 2018 and 2015 IBC and IRC, and 2012 IBC and IRC, respectively
- ANSI A190.1-2017, ANSI A190.1-2012, and ANSI/AITC A190.1-2007 recognized in the 2021 and 2018 IBC and IRC, 2015 IBC and IRC, and 2012 IBC and IRC, respectively

#### 2. Product description:

Shelton glulam columns are manufactured in accordance with ANSI A190.1 using Combination 22 layup recognized in the ANSI 117 *Standard Specification for Structural Glued Laminated Timber of Softwood Species* and *National Design Specification (NDS) Supplement.* It is manufactured in nominal widths of 3-5/16 to 7-1/16 inches, depths ranging from 3-5/16 to 7-1/16 inches, and lengths up to 16 feet.

#### 3. Design properties:

Table 1 lists the allowable design properties for Shelton glulam columns of a solid, rectangular or square cross section.

### 4. Product installation:

Shelton glulam columns shall be installed in accordance with the recommendations provided by the manufacturer and APA Construction Guide: *Glulam Connection Details*, Form T300 (www.apawood.org/resource-library).

## 5. Fire-rated assemblies:

Design of fire-resistant exposed wood members in accordance with Chapter 16 of the *National Design Specification for Wood Construction* (NDS), Section 722.1 of the 2021, 2018, and 2015 IBC, or Section 722.6.3 of the 2012 IBC shall be applicable to Shelton glulam columns. Fire-rated assemblies shall be constructed in accordance with the recommendations provided by the manufacturer and APA Design/Construction Guide: *Fire-Rated Systems*, Form W305 (see link above).

## 6. Limitations:

a) Shelton glulam columns shall be designed in accordance with the code using the design properties specified in this report.

- b) Shelton glulam columns shall have a minimum depth of 3-5/16 inches and a maximum depth of 7-1/16 inches.
- c) Shelton glulam columns are produced at Shelton Structures Inc. dba Shelton Lam and Deck, Chehalis, WA facilities under a quality assurance program audited by APA.
- d) This report is subject to re-examination in one year.

## 7. Identification:

Shelton glulam columns described in this report are identified by a label bearing the manufacturer's name (Shelton Lam & Deck) and/or trademark, the APA assigned plant number (1049), the product standard (ANSI A190.1), the APA logo, the combination symbol, the report number PR-L321, and a means of identifying the date of manufacture.

Table 1. Allowable Design Values for Shelton Glulam Columns for Normal Duration of Load<sup>(1,2)</sup>

	mbination Symbol	Species <sup>(2)</sup>	Grade	All Loading				Axially Loaded			Bending about Y-Y Axis				Bending about X-X Axis		Fasteners
Comb							Compression Perpendicular to Grain		Compression Parallel to Grain		Loaded Parallel to Wide Faces of Laminations				Loaded Perpendicular to Wide Faces of Laminations		Specific Gravity for
											Bending			Shear Parallel	Bending <sup>(6,7)</sup>	Shear Parallel	Dowel-Type
									4 or More Lams	2 or 3 Lams	4 or More Lams 3 Lams	2 Lams	to Grain <sup>(4,5)</sup>	2 Lams to 15 in. Deep	to Grain <sup>(4)</sup>	Fastener Design	
				E <sub>x true</sub> , E <sub>y true</sub> or E <sub>axial</sub> (10 <sup>6</sup> psi)	E <sub>x app</sub> or E <sub>y app</sub> (10 <sup>6</sup> psi)	E <sub>x min</sub> , E <sub>y min</sub> or E <sub>axial min</sub> (10 <sup>6</sup> psi)	F <sub>c⊥</sub> (psi)	F <sub>t</sub> (psi)	F <sub>c</sub> (psi)	F <sub>c</sub> (psi)	F <sub>by</sub> (psi)	F <sub>by</sub> (psi)	F <sub>by</sub> (psi)	F <sub>vy</sub> (psi)	F <sub>bx</sub> (psi)	F <sub>vx</sub> (psi)	SG
:	22	SW <sup>(8)</sup>	L3	1.1	1.0	0.53	315	525	850	725	800	700	575	170	725	195	0.35
	We	et-use factors		0.833			0.53	0.8	0.73		0.8			0.875	0.8	0.875	see NDS

The tabulated allowable design values are applicable only to columns made with a solid, rectangular or square cross section and are for normal duration of loading. For other durations of loading, see applicable building code. The tabulated design values are for dry conditions of use. For wet conditions of use, multiply the tabulated values by the factors shown at the bottom of the table.

<sup>(2)</sup> SW = Softwood species.

The tabulated E values include shear-free (true) modulus of elasticity (E<sub>x true</sub>, E<sub>y true</sub>, and E<sub>axial</sub>), apparent modulus of elasticity (E<sub>x app</sub> and E<sub>y app</sub>), and 5<sup>th</sup> percentile modulus of elasticity (E<sub>x min</sub>, E<sub>y min</sub>, and E<sub>axial min</sub>). For column stability calculation (NDS 3.7.1), E<sub>axial min</sub> shall be used. For calculating column deflections due to lateral loads (used as a beam), the tabulated E<sub>x app</sub> or E<sub>y app</sub> values shall be used unless the shear deflection is determined in addition to bending deflection based on the tabulated E<sub>x true</sub> or E<sub>y true</sub>.

For non-prismatic members, notched members, members subject to impact or cyclic loading, or shear design of bending members at connections (NDS 3.4.3.3), the tabulated F<sub>vx</sub> and F<sub>vy</sub> values shall be multiplied by 0.72.

<sup>(5)</sup> The tabulated F<sub>W</sub> values are for members of 4 or more lams. The tabulated F<sub>W</sub> values shall be multiplied by a factor of 0.95 for 3 lams and 0.84 for 2 lams.

<sup>(6)</sup> The values of F<sub>bx</sub> are based on members 5-1/8 inches in width by 12 inches in depth by 21 feet in length. For members with a larger volume, F<sub>bx</sub> shall be multiplied by a volume factor, C<sub>v</sub> = (5.125/b)<sup>1/10</sup> (12/d)<sup>1/10</sup> (21/L)<sup>1/10</sup>, where b is the beam width (in.), d is the beam depth (in.), and L is the beam length between the points of zero moment (ft).

<sup>(7)</sup> When the member depth is greater than 15 inches, the tabulated F<sub>bx</sub> values shall be multiplied by a factor of 0.88.

When Western Cedars, Western Cedars (North), Western Woods, and Redwood (open grain) are used in combinations for Softwood Species (SW), the design value for modulus of elasticity shall be reduced by 100,000 psi. When Coast Sitka Spruce, Coast Species, Western White Pine, and Eastern White Pine are used in combinations for Softwood Species (SW), tabulated design values for shear parallel to grain, F<sub>vx</sub> and F<sub>vy</sub>, shall be reduced by 10 psi, before applying any other adjustments.

APA – The Engineered Wood Association is an approved national standards developer accredited by American National Standards Institute (ANSI). APA publishes ANSI standards and Voluntary Product Standards for wood structural panels and engineered wood products. APA is an accredited certification body under ISO/IEC 17065 by Standards Council of Canada (SCC), an accredited inspection agency under ISO/IEC 17020 by International Code Council (ICC) International Accreditation Service (IAS), and an accredited testing organization under ISO/IEC 17025 by IAS. APA is also an approved Product Certification Agency, Testing Laboratory, Quality Assurance Entity, Validation Entity, and Product Evaluation Entity by the State of Florida, and an approved testing laboratory by City of Los Angeles.

## **APA - THE ENGINEERED WOOD ASSOCIATION**

#### **HEADQUARTERS**

7011 So. 19<sup>th</sup> St. • Tacoma, Washington 98466 Phone: (253) 565-6600 • Fax: (253) 565-7265 • Internet Address: <u>www.apawood.org</u>

#### PRODUCT SUPPORT HELP DESK

(253) 620-7400 • E-mail Address: help@apawood.org

#### **DISCLAIMER**

APA Product Report® is a trademark of APA – The Engineered Wood Association, Tacoma, Washington. The information contained herein is based on the product evaluation in accordance with the references noted in this report. No warranties, express or implied, including as to fitness for a particular purpose, are made regarding this report. Neither APA, nor its members shall be liable, or assume any legal liability or responsibility, for damages, direct or indirect, arising from the use, application of, and/or reference to opinions, findings, conclusions or recommendations included in this report. Consult your local jurisdiction or design professional to assure compliance with code, construction, and performance requirements. Because APA has no control over quality of workmanship or the conditions under which engineered wood products are used, it cannot accept responsibility for product performance or designs as actually constructed.