

**ANTHONY Power Beam[®] and
Power Rated Glulam (PRG[®])
Anthony Forest Products/Canfor**

PR-L263

Revised February 9, 2017

Products: ANTHONY Power Beam[®] and Power Rated Glulam (PRG[®])
Anthony Forest Products Company, LLC, 309 N. Washington, El Dorado, AR 71730
(800) 221-2326
www.anthonyforest.com

1. Basis of the product report:
 - 2015, 2012, and 2009 International Building Code (IBC): Section 2303.1.3 Structural glued laminated timber
 - 2015 International Residential Code (IRC): Sections R502.1.3, R602.1.3, and R802.1.2 Structural glued laminated timber
 - 2012 and 2009 IRC: Sections R502.1.5, R602.1.2, and R802.1.4 Structural glued laminated timber
 - ASTM D3737-12 recognized by the 2015 IBC and IRC, and ASTM D3737-08 and D3737-07 recognized by the 2012 IBC and IRC, and 2009 IBC and IRC, respectively
 - ANSI A190.1-2012 recognized by the 2015 IBC and IRC, and ANSI/AITC A190.1-07 recognized by the 2012 IBC and IRC, and 2009 IBC and IRC
2. Product description:

Power Beam[®] and Power Rated Glulam (PRG[®]) are Southern Pine structural glued laminated timber manufactured in accordance with ANSI A190.1 using 28F-E1, 28F-E2, 30F-E1, and 30F-E2 for the Power Beam[®] layup combinations, and EWS 24F-V5M1/SP for the PRG[®] layup combination recognized in the 2015 National Design Specification (NDS) Supplement, *APA Glulam Design Specification*, Form Y117 (www.apawood.org/resource-library), or ANSI 117. Power Beam[®] and PRG[®] are used as beams, headers, rafters, or purlins. Power Beam[®] are manufactured in nominal widths of 3, 4, 6, and 8 inches, depths ranging from 5-1/2 to 28-7/8 inches, and lengths up to 60 feet, while PRG[®] is manufactured in nominal widths of 3-1/2 and 5-1/2 inches, depths ranging from 9-1/4 to 18 inches, and lengths up to 60 feet.
3. Design properties:

Table 1 lists the design properties for Power Beam[®] and PRG[®]. The allowable spans for Power Beam[®] and PRG[®] shall be in accordance with the recommendations provided by the manufacturer (www.anthonyforest.com/assets/pdf/power-beam-brochure.pdf and www.anthonyforest.com/pdfs/AFP-PRGTechnicalBrochure.pdf) and *APA Glued Laminated Beam Design Tables*, Form S475 (www.apawood.org/resource-library), as applicable.
4. Product installation:

Power Beam[®] and PRG[®] shall be installed in accordance with the recommendations provided by the manufacturer and *APA Glulam Connection Details*, Form T300 (www.apawood.org/resource-library). Permissible field notching and drilling shall be in accordance with the recommendations provided by the manufacturer and *APA Field Notching and Drilling of Glued Laminated Timber Beams*, Form S560 (www.apawood.org/resource-library).
5. Fire-rated assemblies:

Fire-rated assemblies shall be constructed in accordance with the recommendations provided by the manufacturer and *APA Fire-Rated Systems*, Form W305

(www.apawood.org/resource-library). For one- or two-hour rated glulam beams, Power Beam® and PRG® shall be constructed in accordance with ANSI A190.1 and designed in accordance with the recommendations provided by the manufacturer and APA Technical Note: *Calculating Fire Resistance of Glulam Beams and Columns*, Form Y245 (www.apawood.org/resource-library) or Chapter 16 of the 2015 National Design Specification for Wood Construction (NDS).

6. Limitations:

- a) Power Beam® and PRG® shall be designed in accordance with the code using the design properties specified in this report.
- b) Power Beam® and PRG® shall have a minimum depth of 5-1/2 inches and 9-1/4 inches, respectively.
- c) Power Beam® and PRG® are produced at Anthony Forest Products Company, LLC, El Dorado, AR and Washington, GA facilities under a quality assurance program audited by APA.
- d) This report is subject to re-examination in one year.

7. Identification:

Power Beam® and PRG® described in this report are identified by a label bearing the manufacturer's name (Anthony Forest Products Company, LLC) and/or trademark, the APA assigned plant number (1079 for El Dorado, AR or 1080 for Washington, GA), the product standard (ANSI A190.1), the APA logo, the layup combination symbol, the report number PR-L263, and a means of identifying the date of manufacture.

Table 1. Design Values for PRG® and Power Beam® Manufactured by Anthony Forest Products Company, LLC for Normal Duration of Load ^(1,2)

Symbol	Species Outer/ Core ⁽³⁾ (Bal or Unbal ⁽⁴⁾)	Bending About X-X Axis (Loaded Perpendicular to Wide Faces of Laminations)							Bending About Y-Y Axis (Loaded Parallel to Wide Faces of Laminations)					Axially Loaded		Fasteners			
		Extreme Fiber in Bending ⁽⁵⁾		Compression Perpendicular to Grain		Shear Parallel to Grain ⁽⁶⁾	Modulus of Elasticity ⁽⁷⁾			Extreme Fiber in Bending ⁽⁸⁾	Comp. Perpendicular to Grain	Shear Parallel to Grain ⁽⁶⁾	Modulus of Elasticity ⁽⁷⁾			Tension Parallel to Grain	Comp. Parallel to Grain	Specific Gravity for Dowel-Type Fastener Design	
		Bottom of Beam Stressed in Tension (Positive Bending)	Top of Beam Stressed in Tension (Negative Bending)	Ten. Face	Comp. Face		True	Apparent	Beam Stability				True	Apparent	Beam Stability			Top or Bottom Face	Side Face
		F _{bx} [*] (psi)	F _{bx} ' (psi)	F _{cLx} (psi)		F _{vx} (psi)	E _{x true} (10 ⁶ psi)	E _{x app} (10 ⁶ psi)	E _{x min} (10 ⁶ psi)	F _{by} (psi)	F _{cLy} (psi)	F _{vy} (psi)	E _{y true} (10 ⁶ psi)	E _{y app} (10 ⁶ psi)	E _{y min} (10 ⁶ psi)	F _t (psi)	F _c (psi)	SG	
PRG® 24F-V5M1	SP/SP (B)	2,400	2,400	740	740	300	1.9	1.8	0.95	1,750	650	265	1.6	1.5	0.79	1,150	1,650	0.55	0.55
Power Beam® 28F-E1	SP/SP (U)	2,800	2,300	805	805	300	2.2 ⁽¹⁰⁾	2.1 ⁽¹⁰⁾	1.09 ⁽¹⁰⁾	1,600	650	260	1.8	1.7	0.90	1,300	1,850	0.55	0.55
Power Beam® 28F-E2	SP/SP (B)	2,800	2,800	805	805	300	2.2 ⁽¹⁰⁾	2.1 ⁽¹⁰⁾	1.09 ⁽¹⁰⁾	1,600	650	260	1.8	1.7	0.90	1,300	1,850	0.55	0.55
Power Beam® 30F-E1 ⁽⁹⁾	SP/SP (U)	3,000	2,400	805	805	300	2.2 ⁽¹⁰⁾	2.1 ⁽¹⁰⁾	1.09 ⁽¹⁰⁾	1,750	650	260	1.8	1.7	0.90	1,250	1,750	0.55	0.55
Power Beam® 30F-E2 ⁽⁹⁾	SP/SP (B)	3,000	3,000	805	805	300	2.2 ⁽¹⁰⁾	2.1 ⁽¹⁰⁾	1.09 ⁽¹⁰⁾	1,750	650	260	1.8	1.7	0.90	1,350	1,750	0.55	0.55
Wet-use factor		0.8		0.53		0.875	0.833			0.8	0.53	0.875	0.833			0.8	0.73	see NDS	

⁽¹⁾ The combinations in this table are intended primarily for members stressed in bending due to loads applied perpendicular to the wide faces of the laminations. Design values are tabulated, however, for loading both perpendicular and parallel to the wide faces of the laminations.

⁽²⁾ The tabulated design values are for normal duration of loading. For other durations of loading, see the applicable building code. The tabulated design values are for dry conditions of use. For wet conditions of use, multiply the tabulated values by the wet-use factors shown at the bottom of the table.

⁽³⁾ SP = Southern pine.

⁽⁴⁾ The unbalanced (U) layout is intended primarily for simple-span applications and the balanced (B) layout is intended primarily for continuous or cantilevered applications.

⁽⁵⁾ The values of F_{bx} are based on members 5-1/8 inches in width by 12 inches in depth by 21 feet in length. For members with a larger volume, F_{bx} shall be multiplied by a volume factor, C_v = (5.125/b)^{1/20} (12/d)^{1/20} (21/L)^{1/20}, where b is the beam width (in.), d is the beam depth (in.), and L is the beam length between the points of zero moment (ft).

⁽⁶⁾ For non-prismatic members, members subject to impact or cyclic loading, or shear design of bending members at connections (NDS 3.4.3.3), the F_{vx} and F_{vy} values shall be multiplied by a factor of 0.72. The tabulated F_{vy} values are for timbers with laminations made from a single piece of lumber across the width or multiple pieces that have been edge bonded. For timber manufactured from multiple piece laminations (across width) that are not edge bonded, value shall be multiplied by 0.4 for members with 5, 7, or 9 laminations or by 0.5 for all other members.

⁽⁷⁾ The tabulated E values include true E (also known as "shear-free E"), apparent E, and E for beam stability calculation (NDS 3.3.3.8). For calculating beam deflections, the tabulated E_{app} values shall be used unless the shear deflection is determined in addition to bending deflection based on the tabulated E_{true}. The axial modulus of elasticity, E_{axial} and E_{axial min}, shall be equal to the tabulated E_{y true} and E_{y min} values.

⁽⁸⁾ The values of F_{by} are based on members 12 inches in depth. For depths less than 12 inches, F_{by} shall be permitted to be increased by multiplying by the size factor, (12/d)^{1/9}, where d is the beam depth in inches. When d is less than 3 inches, use the size adjustment factor for 3 inches.

⁽⁹⁾ This layout combination is limited to nominal 6 inches or less in width.

⁽¹⁰⁾ For members of more than 15 laminations, E_{x true} = 2.1 x 10⁶ psi, E_{x app} = 2.0 x 10⁶ psi, and E_{x min} = 1.06 x 10⁶ psi.

APA – The Engineered Wood Association is an approved national standards developer accredited by American National Standards Institute (ANSI). APA publishes ANSI standards and Voluntary Product Standards for wood structural panels and engineered wood products. APA is an accredited certification body under ISO/IEC 17065 by Standards Council of Canada (SCC), an accredited inspection agency under ISO/IEC 17020 by International Code Council (ICC) International Accreditation Service (IAS), and an accredited testing organization under ISO/IEC 17025 by IAS. APA is also an approved Product Certification Agency, Testing Laboratory, Quality Assurance Entity, and Validation Entity by the State of Florida, and an approved testing laboratory by City of Los Angeles.

**APA – THE ENGINEERED WOOD ASSOCIATION
HEADQUARTERS**

7011 So. 19th St. ▪ Tacoma, Washington 98466
Phone: (253) 565-6600 ▪ Fax: (253) 565-7265 ▪ Internet Address: www.apawood.org

PRODUCT SUPPORT HELP DESK
(253) 620-7400 ▪ E-mail Address: help@apawood.org

DISCLAIMER

APA Product Report® is a trademark of *APA – The Engineered Wood Association*, Tacoma, Washington. The information contained herein is based on the product evaluation in accordance with the references noted in this report. Neither APA, nor its members make any warranty, expressed or implied, or assume any legal liability or responsibility for the use, application of, and/or reference to opinions, findings, conclusions, or recommendations included in this report. Consult your local jurisdiction or design professional to assure compliance with code, construction, and performance requirements. Because APA has no control over quality of workmanship or the conditions under which engineered wood products are used, it cannot accept responsibility for product performance or designs as actually constructed.